

playmobil®

6848




WARNING:
CHOKING HAZARD




Small parts. Not for children under 3 years.

“Ne concerne que les USA”



Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!






1.1





1.4



1.5










1.6






1.7







2.1








2.2






2.3






2.4






2.5







2.6





2.7




2.8




3.1




3.2



3.3










3.5



4.1




4.2



4.3



4.4



1

30 60 6292

2

4 2 3
2 2
3 2 4

1

30 22 9382
30 22 9402

2

30 22 9392
30 60 6262

1

30 20 5540
30 60 6272

2

30 09 2110
30 20 5550

30 03 5542
30 60 6282
30 22 9362

30 03 5522
30 22 9362

30 03 5532
30 03 5532

30 20 5010
30 22 9342

1

30 62 1035
30 03 5462

2

30 21 3802
30 03 3462



30 03 5512
30 24 9810
30 03 5512

30 22 2420
30 22 2420

30 21 0990
30 20 9400
30 14 9000

30 80 8372
30 00 7953



30 03 5652



3x 30 03 5612



2x 30 03 5622




30 25 7463



30 03 5982



30 03 5992



2x 30 03 5692



3x 30 03 5802




30 03 5882



30 03 5822



30 03 6012



30 82 7124



30 03 5782



2x 30 03 5892



30 03 5812



2x 30 03 5702



30 03 5792



30 03 5672



30 03 5662



2x 30 03 5842



30 03 5852



30 22 9202



30 03 6002



30 03 6022



30 28 6850



6x 30 20 6790



5x 30 66 7780



2x 30 05 4490



8x 30 21 4942



3x 30 23 8142



2x 30 03 5922



3x 30 21 4632



2x 30 03 5872



2x 30 22 9252



30 03 5962



2x 30 62 0925




4x 30 62 0935



30 65 4093



30 46 2452



30 03 5972



4x 30 03 5832



30 03 5772




4x 30 03 5752



2x 30 03 5762



30 46 2882



4x 30 03 5572



30 03 5682



30 03 5552



30 03 5862



30 03 5502



2x 30 03 5642



2x 30 62 1055



3x 30 22 8852



6x 30 25 7473



30 82 7104



2x 30 03 5732



30 25 9003



30 03 5952



30 82 7114



3x 30 22 9312



2x 30 22 9302



3x 30 24 8370



2x 30 62 1045



30 21 4422



30 28 7640



30 03 5942



30 62 1095



2x 30 03 5712



30 26 1700



30 03 5482



30 03 5632



30 20 9450



30 03 5562



30 02 2142




2x 30 03 5932




30 26 1710



30 03 5472



2x 30 60 1692



30 51 5562



30 51 5572



2x 30 03 5742



4x 30 23 3752



3x 30 22 9462



2x 30 62 0205

6848 + 6518



4x 30 25 4943



4x 30 24 9220



4x 30 27 7830



4x 30 27 7840



3x 30 27 7850



10x 30 25 5502



4x 30 03 5582



4x 30 03 5602



80x 30 09 6900



128x 30 03 6600



4x 30 03 3282



3x 30 03 3312



3x 30 03 5592



2x 30 20 2082




6x 30 03 5902



2x 30 22 9262

6848 + 6519



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēil